



**FLANGE SKILLETS INTERNATIONAL, LLC**  
8687 W. Irlo Bronson Memorial Hwy  
Suite 200  
Kissimmee, FL 34747  
Phone: (337) 322-2271  
Email: sales@flangeskillets.com

# GATOR SKILLET UNPACKING / RIGGING INSTRUCTIONS

Note: Care must be used at all times to protect the sealing surfaces of the gasket. Flange Skillets International, LLC assumes no liability for any damages which may result from the use of our product. User assumes all risks.

**Step 1** Place the gasket on a solid, flat surface



**Step 2** Open the Gator Skillet and place it around the gasket



**Step 3** Make sure the gasket is centered



**Step 4** Install the outside "safety" tie as shown below



**Step 5** Install the center "safety" tie as shown below



**Step 6** Pull the "safety" ties. Verify that the gasket is secure.





**FLANGE SKILLETS INTERNATIONAL, LLC**  
8687 W. Irlo Bronson Memorial Hwy  
Suite 200  
Kissimmee, FL 34747  
Phone: (337) 322-2271  
Email: sales@flangeskillets.com

## **GATOR SKILLET USING THE SKILLET**

Note: The Gator Skillet is designed to be removable. Flange Skillets International, LLC assumes no liability for any damages which may result from the use of our products. User assumes all risks.

**Step 1** Install the flange studs and nuts on the lower half of the flange.

**Step 2** Rest the Gator Skillet / gasket assembly on the installed studs within the flange.

**Step 3** Remove the center "safety" tie first. Since the Gator is self-aligning, the gasket will sit properly in the ring groove.

**Step 4** Remove the outside "safety" tie.

**Step 5** Draw the flanges together to secure the edges of the gasket within the ring groove.

**Step 6** Open the Gator towards the hinge. (Figure 1)

**Step 7** Rotate the Gator around the secured gasket. (Figure 2)  
Lift the Gator to remove it from the flange assembly. (Figure 3)

**Step 8** Continue with the installation of the remaining studs and nuts.



Figure 1



Figure 2



Figure 3